



# SmartBox® A4 and Foolscap Boxes


## Assembly Instructions



50mm deep



100mm deep



150mm deep



XYZ Markers

### Contents:

- 2x Main panels
- 4x Large side panels
- 4x Small Side Panels

1. Once the desired depth size of SmartBox has been chosen, select the appropriate side panels as indicated on the diagrams on the left.
2. Align the matching XYZ markers and push the side panels into the slots on the main panel until they firmly click into place.
3. Complete the assembly by attaching the remaining main panel.

Any unused parts can be returned to KI for recycling

NB. Once the box has been assembled it cannot be dismantled



WORKING  
FOR  
YOU